

RocketRAID 182x S-ATA Controller FreeBSD Installation Guide

Version 1.12

Copyright © 2004 HighPoint Technologies, Inc.

All rights reserved.

Last updated on Jul 11, 2005

Table of Contents

1 Overview	1
2 Installing FreeBSD on RocketRAID 182x Controller	1
Step 1 Prepare Your Hardware for Installation.....	1
Step 2 Check System BIOS Settings.....	1
Step 3 Prepare the Driver Diskette.....	1
Step 4 Install FreeBSD.....	2
3 Installing RR182x Driver on an Existing System	4
Step 1 Copy the Driver Module	4
Step 2 Test the Driver Module	5
Step 3 Configure System to Automatically Load the Driver.....	6
Step 4 Configure System to Mount Volumes when Startup	6
4 Monitoring the Driver	6
Checking Devices Status.....	6
Rebuilding a Critical Array	7
Verifying RAID 1/RAID 5.....	7
5 Updating the Driver	7
6 Installing RAID Management Software.....	9
Checking System Requirements	9
Preparing the Installation Files.....	10
Installing the Software Package	10
Running the Management Software.....	10
7 Uninstalling.....	10
Uninstalling the Driver.....	10
Uninstalling the Management Software.....	11

1 Overview

The purpose of this document is to provide clear instructions on how to install and use RocketRAID 182x Controller on a FreeBSD system.

2 Installing FreeBSD on RocketRAID 182x Controller

If you would like to install FreeBSD onto drives attached to RocketRAID 182x controller, please perform the following operations:

Step 1 Prepare Your Hardware for Installation

After you attach your hard disks to RR182x controller, you can use RR182x BIOS Setting Utility to configure your hard disks as RAID arrays, or just use them as single disks.

Note

If you have other SCSI adapters installed, you must make sure the RR182x controller BIOS will be loaded firstly. If not, try to move it to another PCI slot. Otherwise you may be unable to boot up your system.

Step 2 Check System BIOS Settings

In your system BIOS SETUP menu, change **Boot Sequence** in such a way that the system will first boot from CDROM, next from and then from floppy drive, and then from SCSI. Refer to your BIOS manual to see how to set boot sequence.

If your BIOS settings do not support such a boot sequence, you can first set it to boot from CDROM. After you finish installation, set SCSI as the first boot device to boot up the system.

Step 3 Prepare the Driver Diskette

If you are installing FreeBSD, you must prepare a driver disk for RR182x before installation.

First obtain the driver diskette image file. File `freebsd4x.img` is the driver disk for FreeBSD 4.x, and `freebsd5x.img` is the driver disk for FreeBSD5.x.

On a DOS or Windows system, you can make the boot diskette using `rawrite.exe`. It can be found on the FreeBSD CD (under `\tools`). Just run it under a command window and follow its prompt.

On a FreeBSD system, you can use the “`dd`” command to make the driver diskette. Insert a floppy disk into the floppy drive and type the command:

```
# dd if=freebsd5x.img of=/dev/fd0
```

Step 4 Install FreeBSD

- 1) Start installing the FreeBSD by booting from installation CD.
- 2) If you are installing FreeBSD 5.0 or earlier versions, go to step 3). Else when “Welcome to FreeBSD” screen appears, select “6”, and go to step 5).
- 3) When “Hit [enter] to boot immediately or any other key for command prompt” screen appears, press SPACE key to stop loader from autobooting.

```
BTX loader 1.00  BTX version is 1.01
Console: internal video/keyboard
BIOS driver A: is disk0
BIOS driver B: is disk1
BIOS driver C: is disk2
BIOS 636kB/74512kB available memory

FreeBSD/i386 bootstrap loader, Revision 0.8
(mailto:jkh@narf.osd.bsdi.com, Sat Apr 21 08:46:19 GMT 2001)
-
Hit [Enter] to boot immediagely, or any other key for command prompt.
Booting [kernel] in 9 seconds...
```

<-press SPACE key

A prompted label "ok" will appear at the bottom of the screen.

- 4) If you are installing FreeBSD 4.5 or later, please go to next step. Else type in "load kernel" (without quotation mark) and then press **enter**.

```
Type '?' for a list of commands, 'help' for more detailed help.
ok load kernel
```

```
/kernel text=0x24f1db data=0x3007ec+0x2062c -
```

- 5) Insert RR182x driver diskette into floppy drive now. Type in "load diskx:hptmv-x.x" (without quotation mark) and then press **enter**.

```
for FreeBSD 4.1-RELEASE
ok load disk1:hptmv-4.1

for FreeBSD 4.3-RELEASE
ok load disk1:hptmv-4.3

for FreeBSD 4.4-RELEASE
ok load disk1:hptmv-4.4

for FreeBSD 4.5-RELEASE
ok load disk1:hptmv-4.5

for FreeBSD 4.6.2-RELEASE
ok load disk1:hptmv-4.6.2

for FreeBSD 4.7-RELEASE
ok load disk1:hptmv-4.7

for FreeBSD 4.8-RELEASE
ok load disk1:hptmv-4.8

for FreeBSD 4.9-RELEASE
ok load disk1:hptmv-4.9

for FreeBSD 4.10-RELEASE
ok load disk1:hptmv-4.10
```

```
for FreeBSD 4.11-RELEASE
  ok load disk1:hptmv-4.11

for FreeBSD 5.0-RELEASE
  ok load disk0:hptmv-5.0.ko

for FreeBSD 5.1-RELEASE
  ok load disk0:hptmv-5.1.ko

for FreeBSD 5.2.1-RELEASE
  ok load disk0:hptmv-5.2.1.ko

for FreeBSD 5.3-amd64-RELEASE
  ok load disk0:hptmv-5.3-amd64.ko
  Remove the floppy diskette after loading driver finished

for FreeBSD 5.4-amd64-RELEASE
  ok load disk0:hptmv-5.4-amd64.ko
  Remove the floppy diskette after loading driver finished
```

- 6) Type in "boot" and continue the installation as normal. You can refer to FreeBSD installation guide.

```
ok boot
```

Note

1, For FreeBSD 5.3-amd64-RELEASE and 5.4-amd64-RELEASE, that removing the floppy diskette will prevent the kernel from panic(**Panic isadma_start : bad bounce buffer**) on some motherboard system if you remain the floppy diskette in drive.

2, On some motherboard system, FreeBSD 5.3-amd64-RELEASE and 5.4-amd64-RELEASE can not work well, try to disable the ACPI support in system BIOS setup, or unload the ACPI module when load RocketRAID182x's driver, for example:

```
ok set hint..acpi.0.disabled = "1"
```

```
ok load disk0:hptmv-5.3-amd64.ko
```

3, Since FreeBSD 5.3-LEASE and 5.4-RELEASE natively support RR182x, so you can install OS without these steps, just like install OS onto to the hard drive on the motherboard general IDE port.

4, The system device mapping order is the same as the order shown in RR182x BIOS Setting Utility. If you have no other SCSI devices, the device marked as "BOOT" or "HDD0" will be /dev/da0, "HDD1" will be /dev/da1, "HDD2" will be /dev/da2, etc.

- 7) Before exit install, an additional step must be taken to copy RR182x driver module to system. On the driver disk, there is a setup script "**postinstall**" which will do this work for you. Before you reboot the system, press **Alt-F4** to the command shell and type the following commands:

```
# mount -o ro /dev/fd0 /mnt
# sh /mnt/postinstall
```

```
# umount /mnt
```

Then press **Alt-F1** to return to the setup screen and choose [**X Exit Install**] to finish setup.

3 Installing RR182x Driver on an Existing System

If you are currently running FreeBSD and would like to access drives or arrays attached to the RR182x Controller, you can perform the following steps.

Step 1 Copy the Driver Module

Insert the driver diskette to floppy drive, then using the following commands to copy the driver module:

```
for FreeBSD 4.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.1.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.3-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.3.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.4-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.4.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.5-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.5.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.6.2-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.6.2.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.7-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.7.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.8-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.8.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.9-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.9.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.10-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.10.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.11-RELEASE
# mount -o ro /dev/fd0 /mnt
```

```
# cp /mnt/hptmv-4.11.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 5.0-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.0.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.1.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.2.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.2.1.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.3-amd64-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.3-amd64.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.4-amd64-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.4-amd64.ko /boot/kernel/hptmv.ko
# umount /mnt
```

You can also extract the files from .img files directly, without using a floppy diskette:

```
For FreeBSD 4.x:
# vnconfig vn0c freebsd4x.img
# mount /dev/vn0c /mnt
# cp /mnt/hptmv-xxx.ko /modules/hptmv.ko
# vnconfig -du vn0c myfilesystem mount=/mnt

For FreeBSD 5.x:
# mdconfig -a -t vnode -f freebsd5x.img -u 0
# mount /dev/md0 /mnt
# cp /mnt/hptmv-xxx.ko /boot/kernel/hptmv.ko
# umount /mnt
# mdconfig -d -u md0
```

Step 2 Test the Driver Module

You can test out the module to ensure that it works for your system by load it during system booting.

If the module has been loaded successfully you should see the RR182x banner and a display screen of the attached drives. You can now access the drives as a SCSI device (if you have no other SCSI device, the first device is /dev/da0, then /dev/da1, etc.).

Example

```
F1      FreeBSD
Default: F1

>> FreeBSD/i386 BOOT
Default: 0:ad(0,a)/boot/loader
boot:

BTX loader 1.00  BTX version is 1.01
Console: internal video/keyboard
```

```

BIOS driver A: is disk0
BIOS driver C: is disk2
BIOS 636kB/74512kB available memory

FreeBSD/i386 bootstrap loader, Revision 0.8
(mailto:jkh@narf.osd.bsdi.com, Sat Apr 21 08:46:19 GMT 2001)
Loading /boot/defaults/loader.conf
/kernel text=0x24f1db data=0x3007ec+0x2062c -
<- For FreeBSD 5.1 and later: select "6" on "Welcom to FreeBSD" screen.

Hit [Enter] to boot immediagely, or any other key for command prompt.
Booting [kernel] in 9 seconds...

<-press SPACE key
Type '?' for a list of commands, 'help' for more detailed help.
ok load hptmv
/modules/hptmv.ko text=0xf571 data=0x2c8+0x254
ok autoboot

```

If you have configured a RAID 1/0 using 4 disks, it will be registered to system as device **/dev/da0**. You can use “**/stand/sysinstall**” to create partitions and disklabels (*like da0s1e*) on **da0**. Then you can create new filesystem using “**newfs /dev/da0s1e**”. Now you can mount **/dev/da0s1e** to somewhere to access it.

Step 3 Configure System to Automatically Load the Driver

Most likely, you will not want to type “load hptmv” each time you boot up the system. Therefore you must install the module and tell the system about it. To configure system to automatically load the driver, type in the following commands:

```
# echo 'hptmv_load="YES"' >> /boot/defaults/loader.conf
```

This tells the loader to try loading the RR182x module together with the kernel.

Now, reboot the system. RR182x module should be automatically loaded each time system start up.

Step 4 Configure System to Mount Volumes when Startup

Now you can inform the system to automatically mount the array by modifying the file `/etc/fstab`. E.g. You can add the following line to tell the system to mount `/dev/da1s1e` to location `/mnt/hpt` after startup:

```
/dev/da1s1e      /mnt/hpt      ext2    defaults    0 0
```

4 Monitoring the Driver

Once the driver is running, you can monitor the running status of driver.

Checking Devices Status

Using the following command to show driver status:

```
# sysctl hptmv.status
```

This command will show the driver version number, physical device list and logical device list. And this command will stop beeper when beeping.

Rebuilding a Critical Array

A RAID 1 array or a RAID 1/0 array may become critical after a disk member failed. When an array is in critical status, it will lose the ability of fault tolerance until you finished rebuilding.

Generally rebuilding will automatically start if you have a spare disk or you have put back the failed disk. In these cases, the array only needs to be synchronized to ensure data consistency. If the array is broken, you must first add a disk to the array. To add a disk to an array and start rebuilding, you can use the following command:

```
# sysctl -w hptmv.status="hpt a rebuild b,c"
```

In command, “a” is controller number (0 for first controller and 1 for second controller), “b” is array number as shown in the logical device list. “c” is channel number. E.g.

```
# sysctl -w hptmv.status="hpt 0 rebuild 1,2"
```

will rebuild the array with logical device number 1 using the secondary channel disk on first controller.

If rebuilding cannot be automatically started, you can use command

```
# sysctl -w hptmv.status="hpt a rebuild start"
```

to start rebuilding. To stop the rebuilding process, use command

```
# sysctl -w hptmv.status="hpt a rebuild stop"
```

In command, “a” is controller number (0 for first controller and 1 for second controller).

Verifying RAID 1/RAID 5

To RAID 1/RAID 5, verifying will ensure data consistency.

You can use the following command to start verifying:

```
# sysctl -w hptmv.status="hpt a verify start b"
```

To stop the verifying process, use command:

```
# sysctl -w hptmv.status="hpt a verify stop b"
```

In the command, “a” is controller number (0 for first controller and 1 for second controller), “b” is array number shown in the logical device list.

5 Updating the Driver

You can update the driver if you have newer driver diskette.

- 1) If the driver is installed as a module:

Insert the driver diskette to floppy drive, then using the following commands to update the driver module:

```
for FreeBSD 4.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.1.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.3-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.3.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.4-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.4.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.5-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.5.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.6-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.6.2.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.7-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.7.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.8-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.8.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.9-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.9.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.10-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.10.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 4.11-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-4.11.ko /modules/hptmv.ko
# umount /mnt

for FreeBSD 5.0-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.0.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.1.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.2.1-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.2.1.ko /boot/kernel/hptmv.ko
# umount /mnt
```

```
for FreeBSD 5.3-amd64-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.3-amd64.ko /boot/kernel/hptmv.ko
# umount /mnt

for FreeBSD 5.4-amd64-RELEASE
# mount -o ro /dev/fd0 /mnt
# cp /mnt/hptmv-5.4-amd64.ko /boot/kernel/hptmv.ko
# umount /mnt
```

If you only get the .img file and no floppy disk available, please refer to “Install RR182x Driver on an Existing System”.

Reboot your system to make the new driver take effect.

- 2) Since FreeBSD-5.3-RELEASE and FreeBSD-5.4-RELEASE natively support the RR182x, to update the driver, you need to remove the support in the conf file. Then rebuild the kernel. For example:

```
#cd /usr/src/sys/i386/conf
```

Comment the line in the file GENERIC

```
#device hptmv #Highpoint RocketRAID 182x
```

Apply the conf file and rebuild the kernel, then update the new RR182x driver in the /boot/kernel directory.

6 Installing RAID Management Software

HighPoint RAID Management Software is used to configure and keep track of your hard disks and RAID arrays attached to RR182x controller. Installation of the management software is optional but recommended.

Checking System Requirements

To run the RAID Management GUI, you must have the following software packages installed on your system:

- 1) X-Window system
- 2) gtk library v1.2 or later.
- 3) Compat4.x (for FreeBSD5.x)

If you choose X-User during install FreeBSD system, X-Window system is already installed. Otherwise you may check your system and refer to your FreeBSD system manual for how to install it.

As to gtk library, e.g. you can install them from FreeBSD CD by typing in the following command:

```
# mount /cdrom
# pkg_add /cdrom/packages/All/gtk-1.2.10.tgz
# umount /cdrom
```

As to compat4.x, you can install them from FreeBSD 5.x CD by typing in the following command:

```
# mount /cdrom
# cd /cdrom/compat4x
# ./install.sh
# cd /
# umount /cdrom
```

Preparing the Installation Files

You should have two files to finish the installation.

hptinstall.sh	Installation script file
hptraid.tar.gz	Package of software components

Installing the Software Package

Before the installation, you must log on as root and change the directory to the location where your installation files are. Then you can use the command “./hptinstall.sh -i” to install the software.

The following is an example.

```
[root@tmp]# ls
hptinstall.sh hptraid.tar.gz
[root@tmp]# ./hptinstall.sh -i
Starting hptsvr daemon: [ OK ]
HighPoint ATA RAID Management Software has been installed successfully!
[root@tmp]#
```

Note

If an old version is installed on your system you will be prompted to choose whether to overwrite existing files or not. To continue installation, type in “Y”.

Running the Management Software

You must log on as root to run the management software.

To run the software from a console window, you can just type in “**hptraid**” to start it. If you do not want to block the console, type in “**hptraid&**”.

7 Uninstalling

Uninstalling the Driver

- 1) If the driver is installed as a module, you can uninstall it with following way:

You can only uninstall the driver when your system is not booting from devices attached to RR182x controller. Just remove the line

```
hptmv_load="YES"
```

in `/boot/defaults/loader.conf`, and then delete the driver module `/modules/hptmv.ko` or `/boot/kernel/hptmv.ko`.

- 2) If the driver is built in the kernel, you need to re-build kernel without hptmv, please refer to the above section "Updating the Driver".

Uninstalling the Management Software

Before you uninstall the software, you must log on as root. Then you can use the command "`hptinstall.sh -u`" to uninstall the software.

```
[root@tmp]# hptinstall.sh -u
Are you sure to uninstall HighPoint ATA RAID Management Software?(Y/N)y
Stopping daemon: [ OK ]
Uninstall finished!
[root@tmp]#
```